






# 25-1 ENGINE CONTROLS

2001 F53

For diagnostic information, refer to Powertrain Control/Emission Diagnosis manual.

\* START OR RUN



SEE GROUNDS 10-4